
M120 Product Instruction



Please read this Instruction carefully before using this product and keep it properly

01.Packaging List





Printer *1

User manual*1



USB data wire *1



Adjustable plate *1

02. Device parameters

	Name	Portable label printer	
	Model	M120	
	Print technology	Thermal printing	
	Maximum print width	20~50mm	
	Types of tape	Continuous paper, interstitial paper,Black mark label	
	Label size	57mmX50mm (Max width X Max diameter)	
Hardware	Print speed	70mm/s(switchable,level1-5)	
	Print concentation	Switchable,level1-15	
	Print resolution	203dpi	
	Life of print head	50KM	
	Communication type	Bluetooth4.0	
		Micro USB	
	Battery	1500mAh	
	Product Size	4.3x3.3x2.3in	
	Power Input	5V2A	
	Power Supply Method	Micro USB	
		Lithium battery	
Operatinng Information	Supported operating system	Windows7/8/10	
		Android	
		ios	
	Instruction set	ESC/POS/TSPL	
	Bar code	1D bar code&2D bar code	
	Operating temperature	5°C-50°C	
	Storage temperature	-20°C-60°C	
	Operating humidity	20%-85%	
	Storage humidity	5%95%(Non condensation)	

03.Component instruction



Turn On /off

- (1) Press Power Button for 2 seconds to turn on the printer.
- (2)To turn it off, please press the Power Button for 2 seconds.

Feed


- (1)Label paper /Black mark label: Press Feed Button to feed the tape to the proper place and get ready for printing next tape.
- (2)Continuous paper: Press Feed Button to keep paper feeding. it will stop when you let go of the button.

System Setting

- (1) Press Power Button for 1 second to switch to the setting interface.
- (2)Press Feed Button for 1 second ,scroll option list and select,by
- pressing Power Button
- (3) Press Power Button for 2 seconds to go back to the main page.

04.Installing the Paper Roll

Hold the printer and lift the paper cover



Put the paper roll (Theprint sideshould be below) and push it to the right (Dividing ruler should be above Note the position of the paper rolldevice as shown)



Take out the adjustable plate and remove the left panel



Aim the adjustable plate at both slots and slowly put into the paper bin .



- 5 Press Power button for 2 sec to turn on the paper bin by approximately 15mm) and close the paper cover make sure the paper bin is closed
- 6 Press Power button for 2 sec to turn on the printer ,press feed button to push one piece plate .Connect to the App ,start to use it .






05.Search Print master on App Store or Google Play to Get the App



06.Screen Information



Logo guidance

Bluetooth *

When printer connects to Bluetooth ,this logo will light up .This logo will flash when the data is transferring .

Setting /Transfer 📀

When you are using USB wire ,this logo will be shown as ;If you press Power Button for a short time ,it will be switched to Setting Mode , the logo will be shown as Setting Mode .

Cover Opening N

It indicates that the paper cover is opened or not closed correctly. A message will appear, stating that the paper cover is opened.

Paper Condition 🗵

If the paper roll is not installed correctly, or there is insufficient paper, this logo will light up. A message will appear, stating that there is no paper. When the paper is detected, it will give you a confirmation so that you are able to proceed.

Print Condition 🖶

It will light up while the printer is printing or feeding

External Electricity ♥

It will light up when the printer is connected to a power source.

Charging Battery 🚥

Please charge your printer when the power display begins to flash.

Text Area

This area shows related text information

Screen setting

Options	Parameter	
Language	English ,Chinese	
Print density	1(Lightest),2,3,4(Light),5,6(Normal),7,8,,9,10(Thick). 111213,14,15(Thickest)	
Print speed	1(Slowest),2(Slow).3(Normal),4(Fast),5 (Fastest)	
Paper type	Interstitial paper ,continuous paperBlack mark label	
Automatic shutdown	5min .15min .30min .1h .2h ,4h .8h .24h .No shutdown	
Restore settings	Press power button to restore	
Firmware version	Display Firmware version	
Device address	Display device address	

Screen hint

Content	Condition	
Shutdown	Battery lower than 1%	
Printing	Printing regularly	
Feeding	Press Feed button	
Overheated ,please wait	Print head is overheated	
No paper detected	No paper in the bin or paper is installed incorrectly	
Cover opened	The paper cover is opened	

07.Product warranty

Thank you for choosing the Portable label printer

The free warranty period of this product is one year from the date of purchase (subject to the date of the official purchase invoice).

Within 30 days from the next day of the user signs for receipt, the user may choose to return, replace the goods or enjoy the free maintenance service.

Please keep the warranty card properly, which will not be reissued in case of loss

08. Non-warranty Regulations

The warranty is void under the following conditions:

①Exceeding tuhe warranty period.

②Not presenting the original warranty/maintenance card

- $\begin{tabular}{l} \Preashting a damaged warranty/maintenance card (e.g. tearing or tampering) \end{tabular}$
- Damage caused by unauthorized repair, disassembling, etc.

⑤Damage cauasd by human error.

- © Damage caused by naturel disasters such as earthquakes, floods, windstorms, lightning strikes or externai disasters such as fires and houas collapsas.
- Tailure o damage causad by harsh conditions (oil, moisture, direct sunlight etc.) or failure to use or care for as outlined by the instruction menual.

09.Warranty/MaintenanceCard

Replace		Return	Repair		
	Name:	Gender:	Phone:		
User Information	Address:				
	Date of purch	ase:			
Product Information	Product order number :				
	Product seria	lnumber:			
Reason for Return (Replace/Repair/ Request Malntenance)	Fault descript	ion:			
	Fault conditio	ns:	Maintenance staff:		
Maintenance Records	Processing sit	uation :	Repair date :		
	Repair ticket r	number:	Date of inspection :		